

This section contains general installation information, and describes installation procedures for Bus Based Gateway (BBG) and VME (also called Native ATM) interfaces. See subsection 3.2, page 10, for information on installing BBG interfaces, and see subsection 3.3, page 29, for information on installing VME interfaces.

Installation information

3.1

This subsection contains general installation information that you might need when you install an ATM interface.

Installer qualifications

3.1.1

To install the ATM interface, you should be familiar with the hardware and software for the system on which the ATM is to be installed. Prior experience in upgrading or installing the UNICOS operating system on a Cray Research system is advised. To configure ATM by using the UNICOS Installation/Configuration Menu System, prior knowledge of this menu system is required. (See the *UNICOS Installation and Configuration Tool Reference Manual*, publication SR-3090, for details.)

Removed parts disposition

3.1.2

If you remove parts, return the removed parts to the following address:

Cray Research Inc.
1000 Halbleib Road
Chippewa Falls, WI 54729
USA
Attn., REM

Spares issues

3.1.3

The Cray Research Logistics department reviews all field upgrade notices (FUNs) and determines whether to place spare parts at the country, parts banks, or local depot levels. Contact your local Logistics personnel for local spare parts issues.

Incident reporting

3.1.4

After the upgrade has been installed, the site must complete upgrade incident information within the appropriate database.

Installing a BBG interface

3.2

The following subsections contain the following procedures to install, configure, and test a BBG interface on a Cray Research system with an IOS model E (IOS-E) system:

1. Install UNICOS software
2. Install and verify the HIPPI channel
3. Install the BBG hardware
4. Build the BBG asynchronous software
5. Configure UNICOS for the BBG interface
6. Verify and test the BBG interface

Step 1: Install UNICOS software

3.2.1

Your Cray Research system must be running UNICOS release 9.0 or later. If this is not the case, follow the appropriate UNICOS release 9.0 installation instructions.

Step 2: Install and verify the HIPPI channel

3.2.2

To install the HIPPI channel, follow the instructions in section 3 of the *HIPPI Channel Administrator's Guide*, publication SG-2159. Follow the step-by-step instructions that describe the HIPPI channel installation on Cray Research systems with an IOS-E system.

To verify the HIPPI installation, perform the following steps. If any of the steps fail, correct the failure before moving to the next step. Success of these steps verifies that the HIPPI hardware and software are properly installed.

1. Run the offline HIPPI diagnostics. This step must be performed by the engineer-in-charge (EIC).
2. Attach a HIPPI loopback device to the HIPPI drop cables and run the `/etc/vht` command (see `vht(8)` for options).
3. Attach the HIPPI extension cables and again attach the HIPPI loopback device and execute the `/etc/vht` command.
4. If HIPPI switches are being used, determine the I-field for the Cray Research system, and run the `/etc/vht` command with the *I-field* option. Using the *I-field* option causes the switch to loop the data back to the Cray Research system.

Step 3: Install the BBG hardware

3.2.3

Connect the BBG to the HIPPI channel (or switch) and power it on. Ensure that the BBG front panel LCD display shows the BBG banner and the right hand LED begins to flash on and off about once every second. This will take a few seconds to occur. Following is an example of a BBG banner:

```
BBG V1.0 <ROM>
04/13/95 CRAY-BBG
```

Step 4: Build the BBG software

3.2.4

Copy the BBG software tar file, `bbgrel.tar`, into the directory in which the source will reside. Execute the following commands to extract and install the BBG software:

```
tar xvf bbgrel.tar
install_bbg
```

These commands install the BBG software in the `/usr/lbin/bbg` directory.

Step 5: Configure UNICOS for the BBG interface

3.2.5

To configure the UNICOS operating system for the BBG interface, you can use the UNICOS installation tool (see the following subsection), or you can configure the files manually (see subsection 3.2.5.2, page 22).

*Using the installation tool
to configure the BBG
interface*
3.2.5.1

This subsection describes the steps needed to configure the BBG interface by using the UNICOS installation tool. For information on how to use the installation tool, see the *UNICOS Installation/Configuration Menu System User's Guide*, publication SG-2412, and the *UNICOS Installation and Configuration Tool Reference Manual*, publication SR-3090.

When you configure the BBG interface in the UNICOS operating system, you will be updating the following files:

- /etc/hosts
- /etc/networks
- /etc/config/interfaces
- /etc/config/bbg.config
- /etc/config/bbg.pvc

To configure the BBG interface by using the installation tool, perform the following steps:

1. Enter the UNICOS Installation/Configuration Menu System by entering the following command:

```
/etc/install/install
```

2. Once you are in the UNICOS Installation/Configuration Menu System, it is recommended that before you configure anything with this menu system, you use the `import` utility to update the system configuration. To import the current system configuration into the menu system, go to the `Import Options` option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Utilities
.   .   Import Utility
.   .   .   Import Options
```

3. Set the import options to the following values:

Import Options	
S->	Import root mount point
	Stop import on error? YES
	Import host or guest versions? host
	Reload default import table ...

4. Exit the Import Options option and select the Import Table option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Utilities
.   .   Import Utility
.   .   .   Import Table

```

Set to NO any Import? field parameters that your site does not use. Set the following Import? field parameters to YES:

Import Table					
	Class	Description	Import?	Program	Options
	-----	-----	-----	-----	-----
E->	HARDWARE	Param	YES	hdwparam.	sh-i \$RELEA
	KERNEL	Config.h uts	YES	utsconfh.sh	-i \$RELEA
	KERNEL	Param uts	YES	utsparam.sh	-i \$RELEA
	KERNEL	Comm channels	YES	utscparam.sh	-i \$RELEA
	HOSTS	Hosts	YES	utlimp.sh	hosts
	NETWORKS	Networks	YES	utlimp.sh	networks
	NETIF	Network Interfaces	YES	netifs.sh	-i

5. Exit the Import Table option and select the Import Utility option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Utilities
.   .   Import Utility

```

Set the Import class to run option to ALL, as shown:

```

Import Utility
Import options ==>
M-> Import table ==>
Import class to run      ALL
Run the import process ...

```

6. Execute the Run the import process option. This option overwrites the menu system database. Exit the Import Utility option and answer y (yes) to the following question.

Do you want to continue? **y**

7. Go to the Host Address Configuration option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
.   .   .   .   Host Address Configuration
```

To update the `/etc/hosts` file, use the `[n]` key to enter the host name for the ATM interface. Following is an example of a `/etc/hosts` file:

Host Address Configuration			
Proto	Name	Address	Comment
-----	----	-----	-----
inet	atm01	128.162.102.25	

Following is a description of the configuration parameters:

<u>Parameter</u>	<u>Description</u>
Proto	Specifies the Internet protocol
Name	Specifies the IP address alias
Address	Specifies the standard IP address value

8. Exit the Host Address Configuration option and answer `y` (yes) to the following question:

```
Do you want to update form file? (y/n): y
```

9. To update the `/etc/networks` file, go to the Network Address Configuration option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
.   .   .   .   Network Address Configuration
```

Configure the ATM Internet network address for TCP/IP by creating an entry in the `/etc/networks` file for each ATM network. There will be a network address for each ATM interface that will communicate through TCP/IP. Following is an example of a `/etc/networks` file:

```

Network Address Configuration

      Proto      Name      Address      Comment
      -----      ----      -
E->  inet        atm01     128.162.102.102

```

Following is a description of the configuration parameters:

<u>Parameter</u>	<u>Description</u>
Proto	Specifies the Internet protocol
Name	Specifies the IP address alias
Address	Specifies the standard IP address value

- Exit the Network Address Configuration option and answer `y` (yes) to the following question:

```
Do you want to update form file? (y/n): y
```

- Go to the Network Interface Configuration option, as follows:

UNICOS Installation/Configuration Menu System

```

.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
.   .   .   .   Network Interface Configuration

```

To update the `/etc/config/interfaces` file, use the `n` key to enter the appropriate information to automatically configure up the ATM interface during a UNICOS boot for this system, as shown in the following example:

```

Network Interface Configuration

      Name      Hycf Family      Address Dest Subnet      Type Bcst      MTU Sz
      ----      ---- -
E->  bbg0:atm1      inet        atm01          0xffffffff00  pvc          9176

```

Following is a description of the configuration parameters:

<u>Parameter</u>	<u>Description</u>
Name	Specifies the interface name and ordinal of the ATM interface to be configured. This is the same as the BBG number shown in step 15, page 18.
Hycf	Not used.
Family	Must be set to inet.
Address	Specifies the IP host address for this interface connection. This parameter must be defined in the <code>/etc/hosts</code> file. The address shown in the example is the same as that shown in step 7, page 14.
Dest	Specifies the destination (point-to-point) address. This parameter is not needed for the ATM connection.
Subnet	Specifies the subnetwork address mask to be used for this interface.

<u>Parameter</u>	<u>Description</u>
Type	<p>Specifies the interface type, used to select the type of signaling to be used across the ATM network. These values also imply the type of encapsulation used for IP datagrams. The following are the supported types:</p> <ul style="list-style-type: none"> • <code>pvc</code> – Permanent Virtual Circuit. Implies 802.2 LLC encapsulation • <code>spans</code> – Simple Protocol for ATM Network Signaling (SPANS) protocol. Implies null encapsulation and Switched Virtual Circuits (SVC). • <code>q2931</code> – Q2931 is the Switched Virtual Circuit standard. This is under development and does not currently work. Implies 802.2 LLC encapsulation and Switched Virtual Circuits (SVC). <p>Note: If the interface type is set to <code>pvc</code>, signaling will not be performed on that interface. However, if an interface is marked as <code>spans</code> or <code>q2931</code>, PVCs are still supported on that interface when you use the <code>atmarp</code> command to place them in the <code>atmarp</code> table.</p>
Bcst	Not used.
MTU _{sz}	Specifies an MTU size that is a multiple of 8, ranging from 9176 to 65536.

12. Exit the Network Interface Configuration option and answer `y` (yes) to the following question:

```
Do you want to update form file? (y/n): y
```

13. Go to the General Network Configuration option, as follows:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
```

14. Activate general network configuration, as follows:

```

General Network Configuration

Host address configuration ==>
Network address configuration ==>
Networking services configuration ==>
Network hardware address configuration ==>
Network interface configuration ==>
Import general network configuration ==>
A->Activate general network configuration

```

Answer y (yes) to the following question:

```

Do you want to proceed with the configuration
update?  y

```

15. Go to the Adapter Configuration option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   BBG ATM Configuration
.   .   .   .   Adapter Configuration

```

Use the **[n]** key to enter the appropriate parameters to build the BBG entries in the `/etc/config/bbg.config` file. (If you are creating this file for the first time, the `cfdb/bbgadap.cfg` file (created by the installation tool) is empty. Subsequent installations will show the BBG entries already entered.) Following is an example of an `/etc/config/bbg.config` file:

```

Adapter Configuration

BBG I-Field  HIPPI CHANNEL  CONTROL PATH  ATM  DATA PATH  START
---  -
E-> 0    00000000 /dev/hippi0   1          1    2          YES

```

Following is a description of the parameters:

<u>Parameter</u>	<u>Description</u>
BBG	Specifies the number of the BBG device. Valid values are 0 through 9.
I-Field	Specifies the HIPPI I-field to use for connecting to the BBG.
HIPPI CHANNEL	Specifies the device node to use for connecting to the BBG. A typical example is as follows: <pre> /dev/hippi0 /dev/hippi1 . : .</pre>
CONTROL PATH	Specifies the logical path of the HIPPI channel on which control information will be sent to and from the BBG. This value must be unique. See <code>bbg(4)</code> for details on setting this parameter.
ATM	Defines an ATM interface Sbus slot in the chassis. Indicates the BBG slot in which the ATM card has been placed.
DATA PATH	Specifies the logical path on the HIPPI channel to be used for data input and output. This value must be unique. See <code>bbg(4)</code> for details on setting this parameter.
START	Specifies whether this BBG ATM interface will be started at boot time.

16. Exit the Adapter Configuration option and answer `y` (yes) to the following question:

Do you want to update form file? (y/n): **y**

17. For any remote hosts with which you will communicate by using Permanent Virtual Circuits, go to the Permanent Virtual Circuit Configuration option, as shown:

UNICOS Installation/Configuration Menu System

```

.   Configure System
.   .   Network Configuration
.   .   .   BBG ATM Configuration
.   .   .   .   Permanent Virtual Circuit Configuration
    
```

To update the `/etc/config/bbg.pvc` file, use the `[n]` key to enter the Permanent Virtual Circuits (PVCs) for all remote hosts with which this system will communicate through the BBG interface. Following is an example of a `/etc/config/bbg.pvc` file:

Permanent Virtual Circuit Configuration						
Remote Hostname	Interface	AAL	VPI	VCI	QOS	(Kb/s)
-----	-----	---	---	---	---	-----
E-> atm04	bbg0:atm1	5	0	32	0	

Following is a description of the parameters:

<u>Parameter</u>	<u>Description</u>
Remote Hostname	Specifies the IP host name of the remote host. This name must be located in the <code>/etc/hosts</code> file (see step 7, page 14).
Interface	Specifies the name of the BBG ATM interface that this system will use to reach the remote host. The name is as it appears in the output of the <code>netstat -i</code> command when the interface is configured up.
AAL	Specifies the ATM Adaptation Layer (AAL) to be used by this PVC. This value is based on ATM standards. Currently, the ATM connection supports only AAL 5. Specify this number in decimal form.

<u>Parameter</u>	<u>Description</u>
VPI	Specifies the Virtual Path Identifier (VPI) (sometimes known as the Virtual Path Index). The VPI is placed into each ATM cell header so that the cell can be routed through the ATM network. Currently, ATM interfaces support only VPI 0. Specify this number in decimal form.
VCI	Specifies the Virtual Channel Identifier (VCI). The VCI is placed into each ATM cell header so that the cell can be routed through the ATM network. This number should be between 32 and 1023. Consult your local network administrator when determining the VCI. Specify this number in decimal form.
QOS (Kb/s)	Specifies the quality of service expressed in kilobits per second. This is the peak data rate at which this host will deliver ATM cells to the remote host through the ATM interface. Placing a 0 in this field causes the peak rate control feature to be disabled when sending to this remote host, thus allowing unlimited bandwidth. Specify this number in decimal form.

18. Exit the Permanent Virtual Circuit Configuration menu and answer y (yes) to the following question:

```
Do you want to update form file? (y/n): y
```

19. Go to the BBG/ATM Configuration option, as follows:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   BBG/ATM Configuration
```

20. Activate the BBG/ATM configuration, as follows:

```
BBG/ATM Configuration

Adapter configuration ==>
Permanent Virtual Circuit configuration ==>
Import the BBG/ATM configuration ... ==>
A->Activate the BBG/ATM configuration ...
```

Exit the BBG/ATM Configuration menu and answer *y* (yes) to the following question:

```
Do you want to proceed with the configuration
update?  y
```

21. Exit the UNICOS Installation/Configuration Menu System by typing *q* (quit) and answering *y* (yes) to the following question:

```
Do you want to quit?  y
```

For examples of the files that have been updated by the preceding process, see the following subsections.

Configuring the BBG ATM interface manually

3.2.5.2

The following subsections describe and show examples of each of the files that you must update when you configure the BBG ATM interface manually. These are the same files that are updated by the UNICOS installation tool. The examples in the following subsections show only the part of the files that relate to the ATM interface configuration. Exact parameter settings will be system dependent.

The files to be updated are as follows:

- /etc/config/bbg.config
- /etc/hosts
- /etc/networks
- /etc/config/bbg.pvc
- /etc/config/interfaces

/etc/config/bbg.config
file
3.2.5.2.1

The /etc/config/bbg.config file contains the information necessary for the UNICOS kernel and user commands to communicate with and configure the BBG interfaces.

Create the following parameters in the /etc/config/bbg.config file:

<u>Parameter</u>	<u>Description</u>
<i>bbg.number</i>	The number of the BBG device.
<i>ifield</i>	HIPPI I-field for connecting to the BBG.
<i>infile</i>	HIPPI input device file.
<i>outfile</i>	HIPPI output device file.
<i>atm.number</i>	ATM interface Sbus slot in the chassis.
<i>devtype</i>	Device type. SBA200 is the only valid type.

Following is an example of a /etc/config/bbg.config file:

```
# /etc/config/bbg.config file
.
.
.
bbg0 {
    ifield = 0x0100000c
    infile = /dev/hippi1/i06
    outfile = /dev/hippi1/o06
    atm1 {
        devtype = SBA200
        infile = /dev/hippi1/i05
        outfile = /dev/hippi1/o05
    };
};
start bbg0:atm1 yes
.
.
.
```

/etc/hosts file
3.2.5.2.2

The */etc/hosts* file contains host names. Create the following parameters in this file:

<u>Parameter</u>	<u>Description</u>
<i>address</i>	Standard IP address value
<i>name</i>	IP address alias

Following is an example of a */etc/hosts* file:

```
#/etc/hosts file
128.162.187.1      atm01
.
.
.
```

/etc/networks file
3.2.5.2.3

The */etc/networks* file contains the name and address of your ATM network. Create the following parameters in this file:

<u>Parameter</u>	<u>Description</u>
<i>name</i>	IP address alias
<i>address</i>	Standard IP address value

Following is an example of a */etc/networks* file:

```
#/etc/networks file
atm01      128.162.102
.
.
.
```

Create as many entries as there are ATM interfaces configured for TCP/IP.

/etc/config/bbg.pvc file
3.2.5.2.4

The */etc/config/bbg.pvc* file shows the Permanent Virtual Circuits (PVCs) for all remote hosts that will communicate to the system through the ATM interfaces.

Create the following parameters in the `/etc/config/bbg.pvc` file:

<u>Parameter</u>	<u>Description</u>
<i>remote.host.name</i>	IP host name of the remote host. This name must be located in the <code>/etc/hosts</code> file.
<i>interface</i>	Name of the ATM interface that this system will use to reach the remote host. The name is as it appears in the output of the <code>netstat -i</code> command.
<i>AAL.number</i>	ATM Adaptation Layer (AAL) to be used by this PVC. This value is based on ATM standards. Currently, the ATM connection supports only AAL 5. Specify this number in decimal form.
<i>VPI.number</i>	Virtual Path Identifier (VPI) (sometimes known as the Virtual Path Index), placed into each ATM cell header so that the cell can be routed through the ATM network. Currently, ATM interfaces support only VPI 0. Specify this number in decimal form.
<i>VCI.number</i>	Virtual Channel Identifier (VCI), placed into each ATM cell header so that the cell can be routed through the ATM network. This number should be between 32 and 1023. Consult your local network administrator when determining the VCI. Specify this number in decimal form.
<i>QOS.number</i>	Quality of service expressed in kilobits per second. This is the peak data rate at which this host will deliver ATM cells to the remote host through the ATM interface. Placing a 0 in this field causes the peak rate control feature to be disabled when sending to this remote host, thus allowing unlimited bandwidth. Specify this number in decimal form.

Following is an example of a `/etc/config/bbg.pvc` file:

```

#/etc/config/bbg.pvc file

# hostname      ifc      AAL      VPI      VCI      QOS
# -----      ---      ---      ---      ---      ---
#
atm01          bbg0:atm1  5        0        99       1
shemp01       bbg1:atm1  5        0        99       1
    
```

`/etc/config/interfaces`
file
3.2.5.2.5

The `/etc/config/interfaces` file contains the parameters required to configure up the BBG ATM interface by using the `/etc/initif` script. The `/etc/initif` script is executed automatically when the UNICOS system is booted.

Create the following parameters in the `/etc/config/interfaces` file:

<u>Parameter</u>	<u>Description</u>
<i>name</i>	Interface name and ordinal of the ATM interface to be configured.
<i>family name</i>	Interface family name. Must be designated as <code>inet</code> .
<i>IP.host_address</i>	IP host address for this interface connection. This parameter must be defined in the <code>/etc/hosts</code> file.
<i>hwloop</i>	Allows the packet to go out to the adapter and to come back.
<i>subnet</i>	Subnetwork address mask to be used for this interface.
<i>interface.type</i>	Interface type, used to select the type of signaling to be used across the ATM network. These values also imply the type of encapsulation used for IP datagrams. The following are the supported types: <ul style="list-style-type: none"> • <code>pvc</code> – Permanent Virtual Circuit. Implies 802.2 LLC encapsulation.

<u>Parameter</u>	<u>Description</u>
	<ul style="list-style-type: none"> spans – Simple Protocol for ATM Network Signaling (SPANS) protocol. Implies null encapsulation and Switched Virtual Circuits (SVC). q2931 – Q2931 is the Switched Virtual Circuit standard. This is currently under development and does not currently work. Implies 802.2 LLC encapsulation and Switched Virtual Circuits (SVCs). <p>Note: If the interface type is set to pvc, signaling will not be performed on that interface. However, if an interface is marked as spans or q2931, PVCs are still supported on that interface when you use the atmarp command to place them in the atmarp table.</p>

Following is an example of a /etc/config/interfaces file:

```

#/etc/config/interfaces file
# File format is:
#
# name   hycf_file      family  address          pt-to-pt-dest    args:
#                                               netmask
#                                               iftype
#                                               broadcast
#                                               mtu
#                                               rbuf
#                                               wbuf
#                                               bg
#                                               hwloop
bbg0:atm1  -          inet     atm01  hwloop  netmask 0xffffffff00  iftype pvc

```

Step 6: Verify and test the BBG interface

3.2.6

Perform the following steps to verify and test the BBG interface:

1. Connect a fiber loopback cable on the ATM interface. Prior to running loopback, be sure that the interface is configured down.

2. Run loopback through the BBG device, as follows:

```
/usr/sbin/bbg/progs/bbgatmloop bbgx:atmy
```

`bbgx:atmy` is the name of the BBG and ATM interface in the `/etc/config/bbg.config` file (for example, `bbg0:atm1`).

3. Run loopback again and disconnect the fiber loopback cable while the test is running. Verify that the test stops. This test ensures that the packets are actually arriving at the hardware and coming back
4. Reconnect the loopback cable.
5. Execute the following commands to configure up the BBG and ATM interfaces:

```
/etc/bbgstart  
/etc/initif bbgx:atmy
```

`bbgx:atmy` is the name of the BBG and ATM interface in the `/etc/config/bbg.config` file.

Note: For the `/etc/bbgstart` command to start up the BBG interface, the `/etc/config/bbg.config` file must have the `start` field for `bbgx:atmy` set to `yes`.

6. Ping the Internet address of the Cray Research system on the ATM network.
7. While the `ping` commands are running, disconnect the loopback fiber to verify that the pings are actually going out to the hardware.

Note: The `/etc/config/interfaces` file must specify the `hwloop` parameter, or hardware loopback (`hwloop` option) must have been specified on the `ifconfig(8)` command when the interface was configured up.

8. Connect the ATM interface to the ATM network.

Note: Steps 9 and 10 apply if the ATM network will be using Permanent Virtual Circuits (PVCs).

9. Determine the VCIs to which the BBG will be connecting and add these to the `/etc/config/bbg.pvc` file that was created in step 17, page 20.
10. Configure the Permanent Virtual Circuits (PVCs) in the ATM network (switches and other ATM nodes). You must use Classic IP (RFC 1577) when you set up the ATM PVCs for all of the nodes that will communicate with the Cray Research system.
11. Ping a remote node on the ATM network, as in the following example:

```
ping shemp01
```

Installing a VME interface

3.3

The following subsections contain an installation overview; instructions to install, configure, and test a VME (Native ATM) interface in a CRAY J90 or CRAY EL system; and a list of commands for debugging a VME problem.

Installation overview

3.3.1

The ATM implementation on the CRAY J90 or CRAY EL system consists of a VME module in an open IOS slot. Your site can have a maximum of 16 ATM devices per CRAY J90 or CRAY EL system. Cray Research recommends that only one ATM module reside in each IOS, but supports two ATM modules per IOS. Both synchronous optical network (SONET) and transparent asynchronous transmitter/receiver interface (TAXI) type interface options are supported. Cray Research uses a FORE Systems ForeRunner VMA-200 VMEbus Adapter module for the Native ATM connection.

Software support for the VME connection starts at the UNICOS 8.0.4.1 release for the CRAY J90 series and at the UNICOS 8.0.4A release for the CRAY EL series. ATM adaptation layer 5 (AAL 5) is supported and used for TCP/IP data streams in the UNICOS operating system. Raw I/O is not supported. The UNICOS operating system supports the `atmarp(8)` command for the Permanent Virtual Circuits (PVCs). Switched Virtual Circuit (SVC) support is under development and will be added to the UNICOS system at a later release. SVCs will be supported by means of the Q2931 ATM signaling standard as well as the Simple Protocol for ATM Network Signaling (SPANS) protocol.

Required materials and tools

3.3.1.1

The materials required for the installation include the following:

- ATM modules
- Two fiber-optic cables with Straight Tip (ST) connectors to connect from an ATM switch to the VME ATM module
- UNICOS 8.0.4.1 release or later for the CRAY J90 series and UNICOS 8.0.4A release or later for the CRAY EL series
- The *CRAY EL Series Troubleshooting and Maintenance Manual*, publication CMM-0431-0A0, or the appropriate Field Replacement Procedures.

No special tools are required for this upgrade. You will need the common hand-held tools that are included with the Customer Service toolkit.

Installation step summary

3.3.1.2

To install the VME component into your CRAY J90 or CRAY EL system, perform the following steps. The subsections that follow provide details of these steps.

Note: Before starting the installation, it is recommended that you back up the UNICOS file system.

Note: Some of the installation commands require super-user privilege.

1. Install the software
2. Modify the IOS configuration file
3. Configure UNICOS for the VME interfaces.
4. Install the VME hardware.
5. Load the IOS and boot the system.
6. Test the VME interfaces.
7. Configure up TCP/IP for the VME interfaces.

Step 1: Install the software

3.3.2

Your Cray Research system must be running UNICOS release 8.0.4.1 or later for the CRAY J90 series or UNICOS 8.0.4A or later for the CRAY EL series. If this is not the case, follow the installation instructions that accompany the tape for the appropriate CRAY J90 or CRAY EL UNICOS release.

Step 2: Modify the IOS configuration file

3.3.3

To modify the IOS configuration file, perform the following steps:

1. Edit the IOS configuration file and add the IOS ATM driver to the appropriate IOS files, as follows:

```
exdf -i /config > /tmp/config
vi /tmp/config
```

The following code shows an example of the added IOS ATM driver to the IOS system named `IOS1` in the configuration file:

```
IOS1: 2093 1228800
#-----
/dev/disk
/dev/ipi
/dev/esdi
/dev/atmv
```

Note: The VME connection requires that the `/dev/atmv.cof` file be resident on the IOS. The `atmv.cof` file is the firmware file that is downloaded to the ATM module when the IOS is loaded. The `atmv.cof` file is part of every CRAY J90 or CRAY EL UNICOS release, starting with the UNICOS 8.0.4.1 or 8.0.4A release, respectively.

2. Copy the updated configuration file to the IOS disk, as follows:

```
exdf -ro /config < /tmp/config
```

Step 3: Configure UNICOS for the VME interface

3.3.4

To configure the UNICOS operating system for the VME interface, you can use the UNICOS installation tool (see the following subsection), or you can configure the files manually (see subsection 3.3.4.2, page 43).

Using the installation tool to configure the VME interface

3.3.4.1

This subsection describes the steps needed to configure the VME interface by using the installation tool. For information on how to use the installation tool, see the *UNICOS Installation/Configuration Menu System User's Guide*, publication SG-2412, and the *UNICOS Installation and Configuration Tool Reference Manual*, publication SR-3090.

When you configure the VME interface in the UNICOS operating system, you will be updating the following files:

- /etc/config/param
- /etc/config/atm.pvc
- /etc/hosts
- /etc/networks
- /etc/config/interfaces

To configure the VME interface by using the installation tool, perform the following steps:

1. Enter the UNICOS Installation/Configuration Menu System by entering the following command:

```
/etc/install/install
```

2. Once you are in the UNICOS Installation/Configuration Menu System, it is recommended that before you configure anything with this menu system, you use the `import` utility to update the system configuration. To import the current system configuration into the menu system, go to the Import Options option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Utilities
.   .   Import Utility
.   .   .   Import Options
```

3. Set the import options to the following values:

```
Import Options

S->  Import root mount point
      Stop import on error?           YES
      Import host or guest versions?  host
      Reload default import table ...
```

4. Exit the Import Options option and select the Import Table option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Utilities
.   .   Import Utility
.   .   .   Import Table
```


Set to NO any Import? field parameters that your site does not use. Set the following Import? field parameters to YES:

Import Table					
	Class	Description	Import?	Program	Options
	-----	-----	-----	-----	-----
E->	HARDWARE	Param	YES	hdwparam.sh	-i \$RELEA
	KERNEL	Config.h uts	YES	utsconfh.sh	-i \$RELEA
	KERNEL	Param uts	YES	utsparam.sh	-i \$RELEA
	KERNEL	Comm channels	YES	utscparam.sh	-i \$RELEA
	HOSTS	Hosts	YES	utlimp.sh	hosts
	NETWORKS	Networks	YES	utlimp.sh	networks
	NETIF	Network Interfaces	YES	netifs.sh	-i

5. Exit the Import Table option and select the Import Utility option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Utilities
.   .   Import Utility

```

Set the Import class to run option to ALL, as follows:

```

                Import Utility
                Import options ==>
M->   Import table ==>
                Import class to run      ALL
                Run the import process ...

```

6. Execute the Run the import process option. This option overwrites the menu system database. Exit the Import Utility option and answer y (yes) to the following question:

```

Do you want to continue? y

```

7. Go to the Native ATM Configuration option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Configure System
.   .   UNICOS Kernel Configuration
.   .   .   Communication Channel Configuration
.   .   .   .   Native ATM Configuration

```

Enter the appropriate parameters to build the atmdev entries in the /etc/config/param file, as in the following example:

```

Native ATM Configuration

S->  ATM device ordinal  0
      I/O cluster number 0
      IOP number         0
      IOP Channel number 020

```

Following is a description of the parameters:

<u>Parameter</u>	<u>Description</u>
ATM device ordinal	Specifies the VME interface that will be defined in the param file. Possible values are 0 through 15.
I/O cluster number	Specifies the IOS in which the ATM module will reside. Possible values are 0 through 15.
IOP number	Value must be 0.
IOP Channel number	Specifies the channel number that the I/O processor (IOP) uses to communicate with the ATM module in the IOS. This number is unique to each IOS. Valid values for this field are octal 20 and octal 21. Use octal 20 for the first module and octal 21 for the second module in each IOS or I/O cluster.

Create entries for all VME interfaces that are being installed.

- Exit the Native ATM Configuration option and answer y (yes) to the following question:

```
Do you want to update form file? (y/n): y
```

9. To configure the VME interfaces, go to the Network Parameters option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Configure System
.   .   UNICOS Kernel Configuration
.   .   .   Network Parameters

```

To update the `/etc/config/param` file, enter the appropriate network parameters, as shown in the following example:

Network Parameters	
Number of TCP memory buffers (TCP_NMBSPACE)	4000
Max. Native ATM network devices (atmmxdevs)	2
ATM ARP receive space (atmarp_recv)	131072
ATM ARP send space (atmarp_send)	65536
Max. ATM ARP entries (atmarp_entries)	1024

Following is a description of the parameters:

<u>Parameter</u>	<u>Description</u>
Number of TCP memory buffers (TCP_NMBSPACE)	Specifies the number of mbufs to be defined for the system. This value is system dependent.
Max. Native ATM network devices (atmmxdevs)	Specifies the maximum number of ATM modules allowed for this system. Valid values are 1 through 16. Set this value to the number of ATM interfaces to be installed in this system.
ATM ARP receive space (atmarp_recv)	Specifies the amount of socket receive space used by the <code>atmarp(1)</code> command. This value should always be a power of 2. The default value of 131072 should be sufficient for most systems.

<u>Parameter</u>	<u>Description</u>
ATM ARP send space (atmarp_send)	Specifies the amount of socket send space used by the atmarp(1) command. This value should always be a power of 2. The default value of 65536 should be sufficient for most systems.
Max. ATM ARP entries (atmarp_entries)	Specifies the maximum number of address resolution protocol (ARP) entries allowed in the ATM ARP table. The default value of 1024 should be sufficient for most systems. This value is directly related to the number of remote hosts that communicate through the ATM.

10. To activate the kernel configuration, go to the Activate the Kernel Configuration option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Configure System
.   .   UNICOS Kernel Configuration
.   .   .   Activate the Kernel Configuration

```

Before you answer y (yes) or n (no) to the question, Do you want to proceed with the configuration update?, consider the following conditions:

Because some of the menus are associated with other configuration files, other files than the ones mentioned at the beginning of this subsection will be updated. If you started with the UNICOS Installation/Configuration Menu System that resembles your system's configuration, everything will be updated appropriately. If your system's configuration does not match the UNICOS Installation/Configuration Menu System, answer no to the question and perform step 2, page 32. Otherwise, answer yes.

You need to complete the next two steps only if you will be configuring Permanent Virtual Circuits (PVCs) for remote hosts with which this system will communicate through the VME interface. PVCs provide a means to state a path to a remote host specifically. PVCs are created and deleted by using the atmarp(8) command. The next two steps configure the parameters that will be used by the atmarp(8) command.

Note: Switched Virtual Circuit (SVC) support is under development and will be added to the UNICOS system at a later release. SVCs are a dynamic way to create a path to a remote host. SVCs use a protocol called *signaling* to set up and delete an available path between two hosts. The software performs SVCs automatically.

11. Exit the Activate the Kernel Configuration option and go to the Permanent Virtual Circuit Configuration option, as shown:

```

UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   Native ATM Configuration
.   .   .   .   Permanent Virtual Circuit Configuration

```

To update the `/etc/config/atm.pvc` file, use the `[n]` key to enter the Permanent Virtual Circuits (PVCs) for all remote hosts with which this system will communicate through the VME interface. Following is an example of a `/etc/config/atm.pvc` file:

Permanent Virtual Circuit Configuration					
Remote Hostname	Interface	AAL	VPI	VCI	QOS (Kb/s)
-----	-----	---	---	---	-----
E-> remotehost_atm0	atm0	5	0	32	1
remotehost_atm1	atm1	5	0	33	1

Following is a description of the parameters:

<u>Parameter</u>	<u>Description</u>
Remote Hostname	Specifies the IP host name of the remote host. This name must be located in the <code>/etc/hosts</code> file.
Interface	Specifies the name of the VME interface that this system will use to reach the remote host. The name is as it appears in the output of the <code>netstat -i</code> command.

<u>Parameter</u>	<u>Description</u>
AAL	Specifies the ATM Adaptation Layer (AAL) to be used by this PVC. This value is based on ATM standards. Currently, the ATM connection supports only AAL 5. Specify this number in decimal form.
VPI	Specifies the Virtual Path Identifier (VPI). The VPI is placed into each ATM cell header so that the cell can be routed through the ATM network. Currently, ATM interfaces support only VPI 0. Specify this number in decimal form.
VCI	Specifies the Virtual Channel Identifier (VCI). The VCI is placed into each ATM cell header so that the cell can be routed through the ATM network. This number should be between 32 and 1023. Consult your local network administrator when determining the VCI. Specify this number in decimal form.
QOS (Kb/s)	Specifies the quality of service expressed in kilobits per second. This is the peak data rate at which this host will deliver ATM cells to the remote host through the ATM interface. Placing a 0 in this field causes the peak rate control feature to be disabled when sending to this remote host, thus allowing unlimited bandwidth. Specify this number in decimal form.

12. Exit the Permanent Virtual Circuit Configuration option and answer y (yes) to the following question:

Do you want to update form file? (y/n): **y**

13. To activate the VME (Native ATM) configuration, go to the Activate the Native ATM Configuration option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   Native ATM Configuration
.   .   .   .   Activate the Native ATM Configuration
```

Answer y (yes) to the following question:

Do you want to proceed with the configuration update? **y**

14. Exit the Activate the Native ATM Configuration option and go to the Host Address Configuration option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
.   .   .   .   Host Address Configuration
```

To update the /etc/hosts file, use the **[n]** key to configure the VME connection for TCP/IP. Following is an example of a /etc/hosts file:

Host Address Configuration			
Proto	Name	Address	Comment
-----	----	-----	-----
inet	edge-atm0	128.162.102.25	
inet	remotehost_atm0	128.162.102.30	
inet	remotehost_atm1	128.162.102.31	

Following is a description of the configuration parameters:

<u>Parameter</u>	<u>Description</u>
Proto	Specifies the Internet protocol
Name	Specifies the IP address alias
Address	Specifies the standard IP address value

15. To update the /etc/networks file, go to the Network Address Configuration option, as shown:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
.   .   .   .   Network Address Configuration
```

Configure the ATM Internet network address for TCP/IP by creating an entry in the `/etc/networks` file for each ATM network. There will be a network address for each ATM interface that will communicate through TCP/IP. Following is an example of a `/etc/networks` file:

Network Address Configuration				
	Proto	Name	Address	Comment
	-----	----	-----	-----
E->	inet	atm01	128.162.102.102	

Following is a description of the configuration parameters:

<u>Parameter</u>	<u>Description</u>
Proto	Specifies the Internet protocol
Name	Specifies the IP address alias
Address	Specifies the standard IP address value

- Exit the Network Address Configuration option and go to the Network Interface Configuration option, as follows:

```
UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration
.   .   .   .   Network Interface Configuration
```

To update the `/etc/config/interfaces` file, use the `[n]` key to enter the appropriate information to automatically configure up the VME interface during a UNICOS boot for this system, as shown in the following example:

Network Interface Configuration							
Name	Hycf	Family	Address	Dest	Subnet	Type	Bcst
----	----	-----	-----	----	-----	----	----
lo0		inet	localhost				
en0		inet	edge.cray.com		0xffffffff00		
fddi0		inet	edge-fddi.cray.com		0xffffffff00		128.16
E-> atm0		inet	edge-atm0		0xffffffff00	pvc	

Following is a description of the configuration parameters:

<u>Parameter</u>	<u>Description</u>
Name	Specifies the interface name and ordinal of the ATM interface to be configured. The syntax is atm x , where x is the ordinal number of the ATM interface.
Hycf	Not used.
Family	Must be set to inet.
Address	Specifies the IP host address for this interface connection. This parameter must be defined in the <code>/etc/hosts</code> file.
Dest	Specifies the destination (point-to-point) address. It is not needed for the ATM connection.
Subnet	Specifies the subnetwork address mask to be used for this interface.
Type	Specifies the interface type, used to select the type of signaling to be used across the ATM network. These values also imply the type of encapsulation used for IP datagrams. The following are the supported types: <ul style="list-style-type: none"> • <code>pvc</code> – Permanent Virtual Circuit. Implies 802.2 LLC encapsulation • <code>spans</code> – Simple Protocol for ATM Network Signaling (SPANS) protocol. Implies null encapsulation and Switched Virtual Circuits (SVC).

<u>Parameter</u>	<u>Description</u>
	<ul style="list-style-type: none"> q2931 – Q2931 is the Switched Virtual Circuit standard. This is under development and does not currently work. Implies 802.2 LLC encapsulation and Switched Virtual Circuits (SVC). <p>Note: If the interface type is set to pvc, signaling will not be performed on that interface. However, if an interface is marked as spans or q2931, PVCs are still supported on that interface when you use the atmarp command to place them in the atmarp table.</p>

Bcst Specifies broadcast address.

17. Exit the Network Interface Configuration option and answer y (yes) to the following question:

Do you want to update form file? (y/n): **y**

18. Go to the General Network Configuration option, as follows:

```

UNICOS Installation/Configuration Menu System
.   Configure System
.   .   Network Configuration
.   .   .   General Network Configuration

```

19. Activate general network configuration, as follows:

```
General Network Configuration

Host address configuration ==>
Network address configuration ==>
Networking services configuration ==>
Network hardware address configuration ==>
Network interface configuration ==>
Import general network configuration ==>
A->Activate general network configuration
```

Answer *y* (yes) to the following question:

```
Do you want to proceed with the configuration
update? y
```

20. Exit the UNICOS Installation/Configuration Menu System by typing *q* (quit) and answering *y* (yes) to the following question:

```
Do you want to quit? y
```

For examples of the files that have been updated by the preceding process, see the following subsections.

For the final steps for completing the software installation, see subsection 3.3.4.3, page 50.

*Configuring the VME
interface manually*
3.3.4.2

The following subsections describe and show examples of each of the files that you must update when you configure the VME interface manually. These are the same files that are updated by the UNICOS installation tool. The examples in the following subsections show only the part of the files that relate to the ATM interface configuration. Exact parameter settings will be system dependent.

The files to be updated are as follows:

- /etc/config/param
- /etc/config/atm.pvc
- /etc/hosts
- /etc/networks
- /etc/config/interfaces

/etc/config/param file
3.3.4.2.1

The /etc/config/param file contains the parameters needed to configure the VME interface for the host system.

In the network section of the file, you must create entries for all VME interfaces that are being installed. Enter appropriate values for the following parameters:

<u>Parameter</u>	<u>Description</u>
tcp_nmbspace	Number of TCP memory buffers. Specifies the number of mbufs to be defined for the system. This value is system dependent.
atmmaxdevs	Maximum VME (Native ATM) network devices. Specifies the maximum number of VME modules allowed for this system. Valid values are 1 through 16. Set this value to the number of VME interfaces to be installed in this system.
atmarp_recv	ATM ARP receive space. Specifies the amount of socket receive space used by the atmarp(1) command. This value should always be a power of 2. The default value of 131072 should be sufficient for most systems.
atmarp_send	ATM ARP send space. Specifies the amount of socket send space used by the atmarp(1) command. This value should always be a power of 2. The default value of 65536 should be sufficient for most systems.
atmarp_entries	Maximum ATM ARP entries. Specifies the maximum number of address resolution protocol (ARP) entries allowed in the ATM ARP table. The default value of 1024 should be sufficient for most systems. This value is directly related to the number of remote hosts that communicate through the ATM.
atmdev	ATM device ordinal. Specifies the ATM interface that will be defined in the param file. Possible values are 0 through 15.

<u>Parameter</u>	<u>Description</u>
iopath	I/O path that consists of the following three parameters: cluster, eiop, and channel.
cluster	I/O cluster number. Specifies the IOS in which the ATM module will reside. Possible values are 0 through 15.
eiop	IOP number. This number will always be 0.
channel	IOP channel number. Specifies the channel number that the I/O processor (IOP) uses to communicate with the ATM module in the IOS. This number is unique to each IOS. Valid values for this field are octal 20 and octal 21. Use octal 20 for the first module and octal 21 for the second module.

Following is an example of a `/etc/config/param` file:

```
# /etc/config/param file
.
.
.
network {
    4000 tcp_nmbospace;
    2 atmmaxdevs;
    131072 atmarp_recv;
    65536 atmarp_send;
    1024 atmarp_entries;
.
.
.
atmdev 0 {
    iopath {
        cluster 0;
        eiop 0;
        channel 020;
    }
}
.
.
.
```

`/etc/config/atm.pvc` file
3.3.4.2.2

The `/etc/config/atm.pvc` file shows the Permanent Virtual Circuits (PVCs) for all remote hosts that will communicate to this system through the ATM interfaces.

Create the following parameters in the `/etc/config/atm.pvc` file:

<u>Parameter</u>	<u>Description</u>
<i>remote.host.name</i>	IP host name of the remote host. This name must be located in the <code>/etc/hosts</code> file.
<i>interface</i>	Name of the ATM interface that this system will use to reach the remote host. The name is as it appears in the output of the <code>netstat -i</code> command.

<u>Parameter</u>	<u>Description</u>
<i>AAL.number</i>	ATM Adaptation Layer (AAL) to be used by this PVC. This value is based on ATM standards. Currently, the ATM connection supports only AAL 5. Specify this number in decimal form.
<i>VPI.number</i>	Virtual Path Identifier (VPI), placed into each ATM cell header so that the cell can be routed through the ATM network. Currently, ATM interfaces support only VPI 0. Specify this number in decimal form.
<i>VCI.number</i>	Virtual Channel Identifier (VCI), placed into each ATM cell header so that the cell can be routed through the ATM network. This number should be between 32 and 1023. Consult your local network administrator when determining the VCI. Specify this number in decimal form.
<i>QOS.number</i>	Quality of service expressed in kilobits per second. This is the peak data rate at which this host will deliver ATM cells to the remote host through the ATM interface. Placing a 0 in this field causes the peak rate control feature to be disabled when sending to this remote host, thus allowing unlimited bandwidth. Specify this number in decimal form.

Following is an example of a `/etc/config/atm.pvc` file:

```

#/etc/config/atm.pvc file

# hostname      ifc      AAL      VPI      VCI      QOS
# -----      ---      ---      ---      ---      ---
#
remotehost_atm0 atm0      5         0         32        0
remotehost_atm1 atm1      5         0         33        0

```

/etc/hosts file
3.3.4.2.3

The /etc/hosts file contains host names. Create the following parameters in this file:

<u>Parameter</u>	<u>Description</u>
<i>address</i>	Standard IP address value
<i>name</i>	IP address alias

Following is an example of a /etc/hosts file:

```
#/etc/hosts file

128.162.102.25      edge-atm0
128.162.102.30      remotehost_atm
128.162.102.31      remotehost_atm1
```

/etc/networks file
3.3.4.2.4

The /etc/networks file contains the name and address of your ATM network. Create the following parameters in this file:

<u>Parameter</u>	<u>Description</u>
<i>name</i>	IP address alias
<i>address</i>	Standard IP address value

Following is an example of a /etc/networks file:

```
#/etc/networks file

atm01      128.162.102
.
.
.
```

Create as many entries as there are VME ATM interfaces configured for TCP/IP.

/etc/config/interfaces
file
3.3.4.2.5

The /etc/config/interfaces file contains the parameters required to configure up the ATM interface by using the /etc/initif script.

Create the following parameters in the `/etc/config/interfaces` file:

<u>Parameter</u>	<u>Description</u>
<i>name</i>	Interface name and ordinal of the ATM interface to be configured.
<i>family</i>	Interface family name. Must be set to <code>inet</code> .
<i>IP.host_address</i>	IP host address for this interface connection. This parameter must be defined in the <code>/etc/hosts</code> file.
<i>subnet</i>	Subnetwork address mask to be used for this interface.
<i>interface.type</i>	Interface type, used to select the type of signaling to be used across the ATM network. These values also imply the type of encapsulation used for IP datagrams. The following are the supported types: <ul style="list-style-type: none">• <code>pvc</code> – Permanent Virtual Circuit. Implies 802.2 LLC encapsulation.• <code>spans</code> – Simple Protocol for ATM Network Signaling (SPANS) protocol. Implies null encapsulation and Switched Virtual Circuits (SVCs).• <code>q2931</code> – Q2931 is the Switched Virtual Circuit standard. This is under development and does not currently work. Implies 802.2 LLC encapsulation and Switched Virtual Circuits (SVC). <p>Note: If the interface type is set to <code>pvc</code>, signaling will not be performed on that interface. However, if an interface is marked as <code>spans</code> or <code>q2931</code>, PVCs are still supported on that interface when you use the <code>atmarp</code> command to place them in the <code>atmarp</code> table.</p>

Following is an example of a `/etc/config/interfaces` file:

```

#/etc/config/interfaces file
# File format is:
#
# name   hycf_file      family  address          pt-to-pt-dest    args:
#                                           netmask
#                                           iftype
#                                           broadcast
#                                           mtu
#                                           rbuf
#                                           wbuf
#                                           bg
#                                           hwloop
atm0    -              inet    edge-atm0 -      netmask 0xffffffff00 iftype pvc

```

Completing the software installation

3.3.4.3

To complete the software installation, perform the following steps:

1. Operating from the system console, save the original param file and copy the updated param file to the IOS disk by executing the following commands:

```

% [CONTROL-A] (toggles to the IOS)
IOS> cp /sys/param /sys/param.bak
% [CONTROL-A] (toggles to the UNICOS system)
% exdf -ro /sys/param < /etc/config/param

```

2. Shut down the UNICOS system by executing the following commands:

```

/etc/shutdown 0
[CONTROL-A] (toggles to the IOS)

```

Step 4: Install the VME hardware

3.3.5

The installation of the VME hardware consists of the following procedures:

- Powering down and removing panels
- Setting VMA-200 module switches and jumpers

Note: The labels on the ATM module cables have the following meaning:

Transmit [T] = output
Receive [R] = input



Warning: Before handling any piece of computer equipment, use proper electrostatic discharge (ESD) grounding techniques and wear proper ESD apparel.

Refer to the *CRAY Y-MP EL Troubleshooting and Maintenance Manual*, publication CMM-0431-0B0 and the appropriate Field Replacement Procedures (FRPs) that correspond to the system on which the ATM module will be installed.

*Power down procedure for
CRAY EL systems*
3.3.5.1

Use FRP 2 to power down CRAY EL systems.

*Power down procedure for
CRAY J90 systems*
3.3.5.2

To power down CRAY J90 systems, power down the cabinet, using J90 FRP 1 for an individual cabinet.

*VMA-200 module switch
and jumper settings*
3.3.5.3

This subsection describes procedures for setting VMA-200 module switches and jumpers.

1. Position the module on an electrostatic discharge (ESD) mat or table so that the semiconductor chips are face up and the VME connectors are on the top of the module.
2. Dip switch number 1 (SW1) and dip switch number 2 (SW2) are located on the right side of the module. Set the dip switches to the following settings.

First ATM module in an IOS:

		1	2	3	4	5	6	7	8
SW1	on		X			X	X		
	off	X		X	X			X	X

		1	2	3	4	5	6	7	8
SW2	on	X			X	X	X	X	X
	off		X	X					

Second ATM module in an IOS:

		1	2	3	4	5	6	7	8
SW1	on	X	X		X	X	X		
	off			X				X	X

		1	2	3	4	5	6	7	8
SW2	on	X			X	X	X	X	
	off		X	X					X

3. Ensure that jumper blocks for JP1 are set open for all ATM modules.
4. Insert the ATM modules in the leftmost open slot in the IOS chassis. If there are other open slots in the IOS chassis, ensure that the proper backplane jumpers are installed in the open slots so that all VME signals are available to modules that are located to the right of the open slot. See the *CRAY EL Series Troubleshooting and Maintenance Manual*, publication CMM-0431-0A0, or the appropriate Field Replacement Procedures for more details.
5. Power on the IOS cabinet.

**Step 5: Load the IOS
and boot the system**

3.3.6

To boot the system, perform the following steps from the system console:

1. To load the IOS, enter the following command at the IOS prompt:

```
load
```

If the ATM module is recognized in the IOS, you should see the following message displayed:

```
ATM: Unit 0 - detected
```

If there are two ATM modules in an IOS, you should see the following message also:

```
ATM: Unit 1 - detected
```

If you do not see these messages, you might see the following message:

```
drv_exec: /DEV/ATMV initialization failed
```

If you do see this message, perform the following steps:

- a. Power down the IOS.
 - b. Remove the ATM modules.
 - c. Recheck DIP switch settings.
 - d. Recheck the jumper settings.
 - e. Reinstall the ATM modules.
 - f. Perform the IOS load again.
2. Boot the system to single-user mode by entering the following command:

```
boot
```

3. Enter multiuser mode in the UNICOS system by entering the following command:

```
/etc/init 2
```

Step 6: Test the VME interfaces

3.3.7

To test the VME interface, perform the following steps:

1. Connect one end of an ATM cable to the receive port of the ATM module by connecting the cable to the receive connector (R) at the bulkhead connector.
2. Connect the other end of the same ATM cable used in step 1 to the transmit port of the ATM module by connecting the cable to the transmit connector (T) at the bulkhead connector. There now should be one single strand of fiber connected between the R and T ports of the bulkhead connector. This will form a loopback configuration.
3. Configure down the VME interfaces by using the following command:

```
/etc/ifconfig atm0 down
```

Repeat this command for each VME interface.

4. Configure up each VME interface with hardware loopback turned on for the interface by issuing the following `ifconfig` command:

```
/etc/ifconfig atm0 edge_atm0 netmask 0xffffffff00 hwloop
```

Repeat this command for each VME interface. Change the ATM IP address and network mask values to the site's chosen values.

5. Configure an ATM ARP table entry by issuing the following `atmarp` command:

```
/etc/atmarp -s edge_atm0 atm0 5 0 50
```

Substitute your system's ATM IP address in this command.

6. With the cable connected in loopback configuration (from the transmit connector to the receive connector), use the `ping` command to test the ATM, as shown in the following example:

```
/etc/ping edge_atm0
```

Execute the following command to see the input and output packets (Ipkts and Opkts fields, respectively) for each of the VME interfaces:

```
netstat -i
```

The following example shows the output from a `netstat -i` command:

```
netstat -i
```

Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs
en0	1496	128.162.101	edge	253535	0	61027	0
fddi0	4352	128.162.84	edge-fddi	204070	0	24363	0
atm0	9180	128.162.83	edge_atm0	56	0	56	0
hi0*	65536	none	none	0	0	0	0
lo0	65535	127	localhost	200366	0	200366	0

7. Remove one end of the cable to verify that the ping processes stop. This verifies that the packets are going out of the transmit port of the ATM card and being received through the receive port. If the ping process continues to run, verify that each step in this section was performed.
8. Make the ATM network connection.
9. At this point, you can perform other tests across the loopback connection. Some TCP tests that can be executed are `nettest(8)`, `ftp(1B)`, and `telnet(1B)`.
10. After performing these tests, disable the hardware loopback on each VME interface by executing the following command:

```
/etc/ifconfig atm0 down
```

Repeat this command for each VME interface.

**Step 7: Configure up
TCP/IP for the VME
interfaces**

3.3.8

To configure TCP/IP for the VME interface, issue the `initif` command, as follows:

```
/etc/initif atm0
```

The `initif(8)` command configures up the interface by performing an `ifconfig up` command, and creates `atmarp` entries for each Permanent Virtual Circuit (PVC). Repeat this command for each VME interface.

**Debugging a VME
problem**

3.3.9

You can use the following commands as tools to debug a VME problem:

- `ifconfig(8)`
- `netstat(1B)`
- `atmarp(8)`
- `atmadmin(8)`