

How to use RS232:

Step 1: Connect the RS232 plug of computer to the RS232 socket of scale.

Step 2: Turn on the MS10.

Step 3: Open AccessPort.exe

Step 4: Select View —> Language —> English

Step 5: Select Tools —> Configuration display:

(Note: Select your computer's COM port)



Then Press OK.

Last Display: Press the power symbol and then you are ready to count.



